


*Stair Panel Installation
for Straight Stringers
2CS-AHC
2CS-TBC
2CS-TBB*





2CS Stair Panels enable dado-height 2C (885mm) Finepanels to be seamlessly extended up the stairs

As stair angles vary considerably stair finepanels are supplied as tall rectangles allowing them to be cut to the correct angle top and bottom. Stair panels have their vertical trims attached but not their 'horizontals' - which are supplied in loose lengths for you to cut to the required length and angle before fixing in position

To work out how many stair panels you need measure the **horizontal** distance 'X' between where the top and bottom skirtings meet the straight angled stair skirting or 'stringer'.


Measure top and/or bottom curved stringer(s) **horizontally** between the furthest end of their curve(s)
See - *Classic 2CS-AHC, 2CS-TBC & Beaded 2CS-TBB Stair Installation Guide for Curved Stringers.pdf*
Available to view and print at - www.finepanel.co.uk > *Instructions* > *Stairs 2CS-885mm*




Stair panels do need to be set out carefully - especially if you have half landings or curved stringers. If you would like assistance please e-mail us your stair dimensions, including the lengths of any adjoining straight runs, and we will advise you on the best way to lay the panels out and supply a budget price for the style you are interested in.
E-mail info@finepanel.co.uk

**To be read in conjunction with
a 2C-TBC, 2C-AHC OR 2C-TBB
Installation Guide (Supplied or Online)
www.finepanel.co.uk**

1) - Set out carefully marking vertically up from where skirtings meet the stair stringer (an end trim makes a useful 885mm measuring guide)



2) - Install the lower horizontal run of panels as described in the *Installation Guide* supplied. Cut the last panel of the lower run 22mm wider than where it meets the stringer. Trim any horizontals back 22mm locally. Trim back lower apex to clear stringer.





3i) - Measure horizontally (mm) between vertical markings ('X') and divide by 385 (see table)


If the remainder is less than 225mm see - 3ii) below

If >225mm start with a whole stair panel see - 4)


385 x
2 = 770
3 = 1155
4 = 1540
5 = 1925
6 = 2310
7 = 2695
8 = 3080
9 = 3465
10 = 3850
11 = 4235
12 = 4620
13 = 5005
14 = 5390
15 = 5775



4) - Cut the unprimed 320mm wide spacer board provided to 885mm high to the angle of the stringer at both ends. Optionally use a folded paper template to establish the angle



5) - Use spacer board to mark angles on reverse of panel. Cut to size and attach as for a regular starting panel (pins optional)




IMPORTANT


Remove any staples within 10mm of a cut line
 See - www.finepanel.co.uk > Instructions > Installation Tips & Pictures - All styles.pdf



6) - Cut and fit subsequent stair panels in the usual manner using the spacer board to maintain a regular distance (320mm) between verticals

If the starting panel has been cut - 3ii) - use the spacer board from the second panel onwards




7) - Cut the top (finishing) stair panel 22mm oversize. Trim back the top apex





10) - 'AHC' ONLY
 Angle-cut the mid horizontals
 (2 chamfers) Glue and tape or
 pin centrally - use a template
 made from part the spacer
 board to aid consistency



11) - **ALL STYLES**
 Fill any small gaps,
 rub and dust own lightly.
 Apply 2 coats of paint using
 a small brush and fine
 mini-roller

